

01. Set up your Spider Dome X1, as described in the Spider Dome X1 Setup Guide.

02. The Awning Extension Kit contains:

- 1 x Inflatable Awning
- 2 x Lower Support Bars
- 2 x Middle Support Bars
- 1 x Top Support Bar
- 1 x Awning Extension Banner (optional extra)

03. Attach the awning extension zips at the base of each leg.

04. Zip them up to half height, as shown in the image.

05. At the base of each leg, insert the lower support bars and close the velcro cover. Repeat for the middle and top height support bars.

06. Complete the fastening of the zips so that they meet at the top.

07. Inflate to full pressure using the mains pump or hand pump.

08. Attach the awning extension banner (optional extra).

09. Setup of your awning is now complete. Repeat the process for multiple awnings.

