



Contents

- 1 x Pump with Mains Plug
- 1 x Accordion Hose
- 1 x Inflate/Deflate Nozzle
- 1 x Top Up Nozzle

Inflation

1. Connect the Inflate/Deflate nozzle to the small end of the hose.
2. Connect the large end of the hose to the inflation port on the pump.
3. Plug the pump into a mains power supply.
4. Attach the nozzle to the valve of the inflatable product.
5. Turn on the pump's power switch to begin inflation. Never leave the pump unattended while in use.
6. After inflation, turn off the switch and disconnect the power supply.

Top Up

1. Connect the Top Up nozzle to the small end of the hose.
2. Connect the large end of the hose to the inflation port on the pump.
3. Plug the pump into a mains power supply.
4. Hold the nozzle to the valve of the inflatable product.
5. Turn on the pump's power switch to begin inflation. Never leave the pump unattended while in use.
6. After inflation, turn off the switch and disconnect the power supply.

Deflation

1. Connect the Inflate/Deflate nozzle to the small end of the hose.
2. Connect the large end of the hose to the deflation port on the pump.
3. Plug the pump into a mains power supply.
4. Attach the nozzle to the valve of the inflatable product.
5. Turn on the pump's power switch to begin deflation. Never leave the pump unattended while in use.
6. After deflation, turn off the switch and disconnect the power supply.